


CLAY PIGEON

SET UP GUIDE



DRS100

DRY SET UP:

- Front wheel spacers use minimum of 40mm spacers on inside on front rims
- Stub axle position for track rod - outer holes
- Rear wheel overall width: 138.5cms to 139.5cms
- 3rd bearing - tight without grub screws
- Tyre pressure dry range guide 9.5psi - 11 psi.
- Exhaust flex length 75mm to 85mm
- Always use the same pressure in the fronts and rears.
Look for a working pressure gain of 1 to 2 psi

WET SET UP:

- Use full spacers on the inside of front rim
- Rear wheel overall track: 135cms to 136cms
- In very wet conditions try running 5 to 10 mm toe out on front tracking to increase grip on turn in.
- Stub axle position for track rod - inner holes

TYRE PRESSURES:

- Grease 12 psi wet 15 psi and for monsoon wet 18 psi
- Carb setting start off with 60mins low jet - main jet 83/84
- Designated Sprocket rear size 77t - chain length CZ 102L
- Flex length: 60mm-70mm

DRS

DANIELRICCIARDOSERIES