


# GLAN Y GORS

## SET UP GUIDE



### **DRS100**

#### **DRY SET UP:**

- Front wheel spacers use minimum of 40mm spacers on inside on front rims
- Rear wheel overall width: 138.5cms to 139.5cms
- Tyre pressure dry range guide 9psi - 11 psi.
- Always use the same pressure in the fronts and rears.  
Look for a working pressure gain of 1 to 2 psi

#### **WET SET UP:**

- Full spacers inside front rim
- Rear wheel overall track: 135cms to 136cms
- In very wet conditions try running 5 to 8 mm toe out on front tracking to increase grip on turn in.

#### **TYRE PRESSURES:**

- Grease 12 psi wet 15 psi and for monsoon wet 18 psi
- Carb setting start off with 60mins low jet - main jet 83/84
- Designated Sprocket rear size Junior 76t - chain length CZ 100L
- Flex length: 60mm to 65mm

### **DRS**

DANIELRICCIARDOSERIES