


WHILTON MILL

SET UP GUIDE



DRS125

DRY SET UP:

- Front wheels use minimum of 40mm front spacers on inside/ rear track 138.5cm to 139.5cm.
- Tyre pressure dry range guide 9 to 12 psi.
- Always use the same pressure in the fronts and rears. Look for a working pressure gain of 1 to 2 psi.

WET SET UP:

As it is so cold these will be higher than normal.

- Full spacers on inside, rear track 135cms to 136cms.

TYRE PRESSURES:

- 14 psi grease, 22 psi wet and for monsoon wet 28 psi.
- Carb setting start 60 TO 65mins low jet - main jet 89/90.
- Exhaust flex 60mm - 70mm
- Designated sprocket size: 83T recommended chain length CZ 104L

DRS

DANIELRICCIARDOSERIES